

Bulletin 31/8-2017


Dear all

We have occasionally experienced that sometimes the Control units doesn't keep the settings after a "power down"!

When measuring the battery mounted on the CPU-board inside the Control unit it seems to work properly 3-3,2V

You should verify the contact by holding a meter as shown here (make sure NOT to press on the clip)

If you experience NO contact, you can clean between the battery and the spring clip with a dry piece of paper using only the force from the clip.



Thanks

Torben Jorgensen

CTO

DASPOS A/S